
City & State of Downlink Location Glenwood Springs CO <u>Diagram 05/01/05</u>

BLM Office Glenwood Springs Field Office

Diagram Contact Dan McManus

Diagram Code: GlenwoodCO



## Site Specific Instructions and Comments

Set TV to Channel 4

Set VCR to L2 using the Channel Up/Down. L2 will show in VCR display.

Phone line needs to be connected.

NOTE: TV only has a Coax Input.

Glenwood Springs Field Office Glenwood Springs CO